





# 1




English .....  
 Español 한국어  
 Français 简体中文  
 ..... 繁體中文



# 2





# 3











### POWER OFF



### HOME



[http://rd1.sony.net/help/dmp/nwe390/h\\_ww/](http://rd1.sony.net/help/dmp/nwe390/h_ww/)



### Windows

**Music Center for PC**   
<http://www.sony.net/smc4pc/>

### Mac

**Content Transfer for mac**   
<http://www.sony.net/ct-mac/>